# MFP 3000 G





Version MFP 3000 G is especially tailored to the requirements of the ISO 16890 measurement procedure.

### OPERATION PRINCIPLE

# TESTING FILTER MEDIA BETTER THAN ISO 16890 ROOM AIR FILTERS

Aerosol generation with RBG 1000 G (loading) and PLG 1000 and LSPG 16890 (fractional separation efficiency measurement):

A mass flow controller regulates the dosing air for the RBG 1000 G solid particle aerosol generator, the PLG 1000 liquid aerosol generator, and the LSPG 16890 salt aerosol generator. This ensures the same operating conditions are always maintained.

DLB 2000 compressed air humidifier for the dispersion air:

Dry compressed air is generally used for the aerosol generation, whereby, at the very low volume flows in filter media testing, the rel. humidity of the test volume flow can drop considerably. The DLB 2000 compressed air humidifier can condition the rel. humidity and temperature of the RBG 1000 dispersion air precisely to the required values, thus minimizing the influence of rel. humidity on the dust holding capacity to be measured.

Aerosol inlet and aerosol neutralization on MFP 3000 G:

The aerosol inlet on the MFP 3000 G neutralizes the test aerosol. It ensures a homogeneous distribution of the test aerosol in the raw gas channel. The simple construction allows rapid replacement of the aerosol generator, and the raw gas channel is easy to clean.

This special aerosol inlet allows simultaneous connection of all aerosol generators, such that the test sequence can be mainly performed automatically.

welas® 2300 aerosol sensors:

The welas® 2300 high-concentration sensors ensure unambiguous and coincidence-free fractional separation efficiency and excellent count statistics with DEHS. These sensors are also fitted with a special aerosol guide that minimizes contamination of the internal optics.

#### Software:

In the sequence program for the ISO 16890 measurement procedure, the individual test steps - differential pressure measurement, fractional separation efficiency measurements - and the various differential pressure levels can be set for loading in accordance with ISO 16890 requirements. The precise definition of the test parameter



pre-programmable sequence programs ensures a very high level of comparability of the results. The evaluation and creation of the test record in accordance with ISO 16890 is included in the software supplied.

Version: July 11, 2025 Page 2 of 5 MFP 3000 G



# **BENEFITS**

- Virtually simultaneous particle measurement in the raw gas and clean gas
- Particle size measurements from  $0.2 40 \mu m$
- Measurement of  $C_{n \text{ max}} = 4x10^4 \text{ particles/cm}^3 \text{ without dilution}$
- Internationally comparable measurement results
- Widespread distribution of the measurement system
- High reproducibility of the testing method
- Easy use of different test aerosols, e.g. SAE Fine and Coarse, NaCl/KCl, DEHS
- Highest raw gas concentrations of up to  $> 70 \text{ mg/m}^3$  (ISO Fine) or  $> 300 \text{ mg/m}^3$  (ISO Coarse) with measurement of the fraction separation efficiency for burden tests
- Flexible filter test software FTControl
- Sequence programs for pressure loss measurements, measurements of fraction separation efficiency and burden measurements
- Easy to operate, even untrained personnel can be instructed quickly in the use of the equipment
- Short set-up times
- Cleaning and calibration can be performed autonomously by the customer
- Easy use of the measurement technology components even in other applications
- Mobile setup, easy to move on castors
- Reliable operation
- · Validation of the clear function of individual components and the overall system during pre-delivery acceptance testing and upon delivery
- Low-maintenance
- The unit will reduce your operating costs

MFP 3000 G Page 3 of 5



# **DATASHEET**

| Aerosols                          | Dusts (e.g., SAE dusts), salts (e.g., NaCl, KCl), liquid aerosols (e.g., DEHS) |
|-----------------------------------|--|
| Test area of the medium           | 100 cm <sup>2</sup>  |
| Measurement range (size)          | 0.2 – 40 μm  |
| Measurement range (mass)          | Up to 1,000 mg/m³ (depending on the version)                                   |
| Volume flow                       | $1-35~\mathrm{m}^3/\mathrm{h}$ - suction mode                                  |
| Differential pressure measurement | 0 – 1,200 Pa selectable, 0 – 2,500 Pa selectable, 0 – 5,000 Pa selectable      |
| Inflow velocity                   | 5 cm/s – 1 m/s (others on request)   |
| Compressed air supply             | 6 – 8 bar  |
| Dimensions                        | 2.500 • 680 • 1.550 mm (H • B • T)   |

MFP 3000 G



# **APPLICATIONS**

- Testing of filter media and small filter elements in product development and during production monitoring.
- Testing option based on ISO 16890 (General ventialtion air filters), the test procedure according to ASHRAE 52.2 or EN 779 is optinal available.



Mehr Informationen: https://www.palas.de/product/mfp3000g