FET 600





The FET 600 enables defined testing of filter elements up to 610 • 610 mm, such as ventilation filters, HEPA/ULPA filters, vacuum cleaner filters, and car cabin filters. Designed for optimum flow guidance, the channel can also use adapters for smaller filter elements. Coarse filters up to ULPA filters are tested for separation via particle size and differential pressure.

Thanks to individual adapters and customer-specific adaptations in the air duct, the FET system can be used for a wide variety of filter elements.

工作原理

TEST SYSTEM FOR LARGE FILTER ELEMENTS UP TO A CROSS-SECTIONAL AREA OF 610 MM

A controlled fan sucks a defined test volume flow from the environment via a HEPA inlet filter through the test duct and a protective filter.

The aerosol and pressure are operated on the upstream side of the FET 600. In the vertically constructed test duct, the aerosol is then homogeneously mixed and directed onto the filter element.

The aerosol extraction for the particle measurement is representative of the raw and clean gas side, considering the isokinetic. Two measuring devices can be used simultaneously, or only one measuring device with a measuring point switch.

The measuring instruments used are the Palas U-SMPS 1 or the aerosol spectrometers of the Promo 8 system 2 , which can cover a measuring range from 0.01 to 40 μ m, depending on the selection.

Now the filter element is inserted into the test channel. The filter holder can be easily and quickly opened pneumatically for this purpose. Individual adapters can be made for different designs of filter elements.

Now the filter element is tested. The pressure drop, clean gas concentration, and size of the clean gas aerosol are determined, and fractional separation efficiency is calculated.

The system is easily controlled via the integrated FTControl³ test rig control system. Individual sequence programs ensure that the measurements are carried out safely.

 $^{^1}$ U-SMPS: https://www.palas.de/zh//zh/product/usmps

 $^{^{2}} Promo \\ \hbox{$\mathbb{R}$ system: https://www.palas.de/zh//zh/product/promo}$

 $^{^3}$ FTControl: https://www.palas.de/zh//zh/product/software-ftcontrol



A comprehensive analysis section allows a simple and fast evaluation of the measurement results.

Extensions/Accessories

Aerosol generation

Due to the modular design, various test aerosols can be generated depending on the aerosol generator used: DEHS, oils, paraffin oil, NaCl, or KCl.

Aerosol discharge

Depending on the application, the aerosol discharge is carried out via the electrical corona discharge CD 2000^4 or the X-ray source XRC 049^5 , which is not subject to approval.

Aerosol dilution

The dilution systems of the VKL series 6 are to be used especially when measuring high HEPA filter qualities (filter efficiency >99.95%). When using dilution systems, a measuring point switch for the dilution factor (1,10,100,1000,10000) is used for easy filter testing.

Aerosol measurement

The aerosol measurement takes place

- in the range from 0.01 to max. 1.2 μ m with the Palas U-SMPS⁷,
- in the range from approx. 0.12 to 100 μ m with the aerosol spectrometer of the Promo [®] system⁸.

The two measuring instruments can be combined and used simultaneously as a U-Range⁹ for the entire range.

 $^{^4}$ CD 2000: https://www.palas.de/zh//zh/product/cd2000

 $^{^5}$ XRC 049: https://www.palas.de/zh//zh/product/xrc049

⁶VKL series: https://www.palas.de/zh//zh/product/vkl

 $^{^{7} \}text{U-SMPS: https://www.palas.de/zh//zh/en/product/usmps}$

 $^{^8} Promo @ \ system: \ https://www.palas.de/zh//zh/product/promo$

 $^{^9\}text{U-Range: https://www.palas.de/zh//zh/product/seriesurange}$



优势

- Measurement according to ISO 29463-5 and ISO 16890 (ISO ePM_1 ; ISO $ePM_{2.5}$) in one channel
- Double channels on request
- Particularly wide range of applications for separation efficiency measurement from 0.02 to 3 μm
- Customization possible for optimal test execution
- Horizontal design to minimize particle losses
- Easy to use for filter elements as well as for material testing (adapter required)
- Logged results based on the relevant standards
- Test benches tested and calibrated ex works

标准和证书

ISO 29463-5, ISO 16890



技术数据

气溶胶	Dusts (e.g., SAE dusts), salts (e.g., NaCl, KCl), liquid aerosols (e.g., DEHS), latex particles (PSL)
测量范围(总穿透率)	Up to 0.0005 %
测量范围(粒径)	0.02–100 μm
体积流量	40–1,500 m ³ /h -pressurized operation
Differential pressure measurement	0 – 1,200 Pa selectable, 0 – 2,500 Pa selectable, 0 – 5,000 Pa selectable
Size filter element	610 • 610 • 610 mm (H • W • D)



应用领域

- Development
- Quality control for
 - Cabin filters
 - HEPA/ULPA clean room filters
 - Cabin air filters
 - Engine air filters
 - Compressor supply air filters
- Measurement of MPPS according to ISO 29463-5
- Measurement of the fractional separation efficiency according to ISO 16890
- Determination of the pressure loss at different volume flows



Mehr Informationen:

https://www.palas.de/zh/product/FET600