

AGF 2.0 iP



The AGF 2.0 iP aerosol generator can atomize liquids with a binary nozzle.

Unlike the other versions in the AGF series, the AGF 2.0 iP has a built-in pump that generates volume flow, making an additional compressed air connection unnecessary to operate the device.

优势

- No compressed air required during operation
- Exact adjustment of the operating parameters
- Number concentration (C_N) can be varied by the factor of 10
- Particle size distribution remains virtually constant if C_N is modified
- Number distribution maximum is within the MPPS range
- Virtually no power losses
- Optimal concentration, no coagulation losses
- Resistant to numerous acids, bases, and solvents
- Robust design, stainless steel housing
- Easy to operate
- As opposed to the collision method, AGF 2.0 does not generate particles $> 2 \mu\text{m}$ thanks to its cyclone.
- Because the AGF generates virtually no droplets $> 2 \mu\text{m}$, the consumption of materials is very low, thus ensuring a long dosing time.
- With the use of DEHS, the mean particle size is within the MPPS range for HEPA/ULPA filters

应用领域

- Clean room technology
 - Acceptance tests and leak tests as per ISO 14644 and VDI 2083
 - Leak tests, fit testing
 - Recovery tests
- Filter testing, quality control
 - Filter cartridges
 - Car interior filters
 - Filter media, particulate air filters
 - Aerosol generation for MPPS determination of HEPA/ULPA filters
- Tracer particles
 - Inhalation experiments
 - Optical flow measurement procedures with positive pressure values of up to 10 bar (model version AGF 2.0 D)
 - LDV
- Calibration of counting particle measurement methods
 - Nebulization of latex suspensions $< 1 \mu\text{m}$
- Smoke detector test

技术数据

体积流量	12 – 14 l/min	Mass flow (particles)	< 2 g/h (DEHS)
Filling quantity	300 ml	电源	115 – 230 V, 50/60 Hz
Particle material	DEHS, DOP, Emery 3004, paraffin oil, other non-resinous oils	Dosing time	> 24 h
Compressed air connection	No	Aerosol outlet connection	Ø _{inside} = 6 mm, Ø _{outside} = 8 mm
Mean particle diameter (number)	0.25 µm	Particle diameter (maximum)	2 µm
Dimensions	325 • 300 • 175 mm (H • W • D)	重量	Approx. 15 kg

标准和证书

ISO 14644, VDI 2083