

MSS 08



The Multi Sampling System MSS 08 enables the connection of central measuring devices (e.g., UF-CPC¹ or ENVI-CPC²) up to eight different sampling ports and easy switching between them. This can be useful, e.g., for nanoparticle concentration monitoring in different rooms or along a process with a single measuring device.

工作原理

MULTI SAMPLING SYSTEM FOR AUTOMATED SWITCHING BETWEEN 8 SAMPLING PORTS

The operation is based on a multiposition valve, and a sampling port can be selected via an integrated graphical user interface on the measurement device itself or directly via remote control on the MSS 08. It is possible to directly select a specific sampling port or use the auto-switching mode with sequential series of the different sampling ports. The user can freely adjust timing and delay time.

Included in the scope of delivery is extra software for monitoring the concentration of all sampling ports and displaying them on an external monitor or panel, which are connected to the measurement device via (company-)network.

Additional monitoring screens can be ordered separately.

¹condensation particle counter UF-CPC: <https://www.palas.de/zh//zh/product/ufcpc>

²condensation particle counter ENVI-CPC: <https://www.palas.de/zh//zh/product/envicpc>

优势

- Automatic change between 8 measuring positions
- Reduces acquisition and operating costs

技术数据

体积流量	0 – 10 l/min
电源	115 – 230 V, 50/60 Hz
Response time	3 s (for change of position)
Aerosol inlet connection	8 mm

应用领域

- Air quality surveillance in different rooms
- Process monitoring on multiple positions



Mehr Informationen:
<https://www.palas.de/zh/product/mss08>